

Work Order ID 108651

108651

Page 1

October-25-13 1:55:49 PM

Item ID: D412-761-041

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Full Vertical Reference Door Mod, (Wide)

Start Date: 10/25/13 Start Qty: 1.00 ***1***

Cust Item ID:

Required Date: 10/28/13 Req'd Qty: 1.00 ***1***

Customer:

Reference:

Approvals: Process Plan: W Date: _____ Tooling: _____ Date: _____

Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
IIN D412-761	Rev E								
100		0.00							
100	DOCUMENT CONTROL								
DC	Memo	0.00							
Document Control	Photocopy bluefile & type labels per PPP D412-761-041 CHG002								
110	Pick Kit	0.00							
110									
Packaging	Memo	0.00							
Packaging									
120	QC4- 100% Inspect kits for completeness	0.00							
120									
QC	Memo	0.00							
Quality Control									

SD 13/10/25
DAS 6 9-89

DAS 31 9-89
13/10/25

DAS 6 9-89
13/10/25

Work Order ID 108651

October-25-13 1:55:49 PM

108651

Page 2

Item ID: D412-761-041

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Full Vertical Reference Door Mod, (Wide)

Start Date: 10/25/13 Start Qty: 1.00 ***1***

Cust Item ID:

Required Date: 10/28/13 Req'd Qty: 1.00 ***1***

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D412-761-041								
	Location: _____								
	PPP Rev: _____								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

SL 13/10/25

MLJ 13-10-25

13-10-25

Picklist Print

October-25-13 1:55:48 PM

Page 1

Work Order ID: 108651

Parent Item: D412-761-041

Start Date: 10/25/13

Required Date: 10/28/13

Parent Item Name: Full Vertical Reference Door Mod, (Wide)

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:A 09-01-13 rev.C as per dwg DD verified by:EC IPP Rev:B as per ECN10-573 DD 10.05.18 verf:EC IPP Rev:C 13.01.15 as per ECN13-511 DD Verf:JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D412-761-045 Bubble Window		Manufactured	No			110	Each	0.0000	1	1			DAS
D412-761-047 Instrument Panel		Manufactured	No			110	Each	1.0000	1	1			31 9-89
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					DAS
				FG043		1							31 9-89
				106414		1							
D412-761-049 Armrest		Manufactured	No			110	Each	1.0000	1	1			
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					DAS
				FG030		1							31 9-89
				56896		1							

DAS
6
9-89

DAS
6
9-89